

BLMPS MON12 25/5C4

**Technical Manual
Power supply**

Version 00

BRUKER

The information in this manual may be altered without notice.

BRUKER accepts no responsibility for actions taken as a result of use of this manual. BRUKER accepts no liability for any mistakes contained in the manual, leading to coincidental damage, whether during installation or operation of the instrument. Unauthorised reproduction of manual contents, without written permission from the publishers, or translation into another language, either in full or in part, is forbidden.

This manual describes the units as they are at the time of printing. On request, the manufacturer shall supply circuit diagrams, lists of components, descriptions, calibrating instructions and any other information for use by qualified personnel of the user, in charge of repairing the parts of the unit which have been stated by the manufacturer to be "repairable". Such supply shall in no event constitute permission to modify or repair the units or approval of the same.

All rights reserved for the units, circuits, processes and appellations mentioned herein.

This unit is not designed for any type of use which is not specifically described in this manual. Such use may be hazardous.

This manual was written by

FRISON SERGE

Wissembourg, France

Unit P/N W1211976

Manual P/N : W1211984

Contents

	Contents	5
	Index	7
1	Generalities	9
1.1	Power supply identification	9
1.2	Output specifications	9
1.3	Input specifications	10
1.4	Stability $\Delta I/I$ at I Max	11
1.5	Installation	12
1.6	Service information and maintenance	13
1.7	Technical contact	14
2	Wiring diagrams	15
2.1	BPS Local control unit BMC20-6 Blind	16
2.2	BPS Local control unit BMC20-6 2xRS232C+IEEE	17
2.3	BPS Local control unit BMC20-6 2xRS232C+IEEE	18
2.4	Power module Mon 2 1/2	19
2.5	Power module Mon 2 2/2	20
3	Local control unit electronic boards	21
3.1	Auxiliary power supply	22
3.2	Power supply controller unipolar	23
	ADC 12 Bitt	24
	DAC 16 Bit & Regulation	25
	Output stage	26
	PAL	27
	P.S Controller Jumper & Layout	28
	P.S Controller Board adress	29
3.3	Relay in/out	30
	Relay	31
	InputsI	32
	PAL 22V10	33
	Layout and jumper configuration	34
3.4	CPU & 2x RS232	35
	2x RS232 interfacet	36
	Jumper configuration 1x RS232C	37
	PAL 22V10	38
	PAL 16V8	39
	PAL 22V10	40
	PAL 22V10	41

4	REM.CONTROL UNIT ELCTR.BOARDS	43
4.1	Display BMC20	44
	Alpha numeric display	45
	Keyboard BMC20	46
4.2	Display PIO	47
	Key and Led I/O	48
4.3	Parallel I/O	49
	Layout	50
5	Cabinet electronic boards	51
5.1	UCM (universal control module)l	52
	UCM	53
	UCM	54
	UCM	55
5.2	Mains control	56
5.3	Power stage	57

Index

Generalities

1

Power supply identification

1.1

UNIT/TYPE	BLMPS MON12 25/5C4	DATE	05/2002
SERIAL N°	W1211976	TESTED BY	L.MISLIN
CUSTOMER	BATAVIA ILLINOIS	SIGNATURE	

Output specifications

1.2

CHANNEL	OUTPUT VOLTAGE	OUTPUT CURRENT	OUTPUT POWER	LOAD RESISTANCE
1	25V	5A	125W	5 ohm

Power line

Type :

- Mono phase X
- Three phase
- With neutral
- Without neutral

Voltage..... 120 V

Current 5 A

Nominal power 0.6 KVA

Auxiliary line

Voltage..... 120V

Current 1.2A

Cooling mode

- Air X
- Water

Max input pressure 10 Bars

Water circuit tested at 16 Bars/1H

Minimum flow rate..... 6 l/mn

Requested delta pressure in/out.....3.5 Bars

Max water input temperature 30°C

Ambiant air

Max temperature 30°C

Stability $\Delta I/I$ at I Max

1.4

Stability $\Delta I/I$ at I max

Warmup time = 30mn

DC to 10Hz..... per mn $2 \cdot 10^{-4}$

DC to 10Hz..... per 8 hours $1 \cdot 10^{-3}$

Temperature coef

Shunt..... +/-25 ppm/°C

Regulation 25 ppm/°C

Cabinet

- Dimensions
 - Height 132.5 mm
 - Length..... 483 mm
 - Depth 464 mm
- Weight 35 kg

A minimum distance of 20 cm must be respected between the cabinet and the wall. The top and the bottom of the cabinet must be kept free for an optimal air flow.

Connect the water cooling tubes respecting the indications written on the label.

IN : cold water input

OUT : water output

Connect the line input cables and the PE (protective earth) to the input terminals.

Adapt the cable section to the power consumption which is indicated on chapter «specifications».

Connect the load to the «DC out» terminals. Adapt the cable section to the driven load current.

Connect all other cables (interface, control...).

Connect the magnet interlock (external security)

The terminals must be short circuited for normal running.

The supply will stop by opening the loop.

Don't apply any voltage on these terminals.

Don't never disconnect any cables during running of the supply. Risk of electrical arcs and shocks.

Don't never splash or pour any liquid on the cabinet. Use alcohol and a rag for cleaning.

The produced magnetic field can affect pace maker. Concerned people should not come close to the equipment.

Be careful for service requiring line supply. Voltage is present on any printed circuit boards and components.

In some conditions, voltage can be induced between analog ground and protective earth on power supplies with floating analog ground or equipped with a fuse ground fault detector.

MAINTENANCE :

Caution : Risk of electrocution.

Disconnect the mains before any operation.

For an optimal running, check every 6 months following points.

State and tightness of all water tubes and connections.

«Water flow» fault indication of the flow meter.

State of the transistor fuses. Blow fuses must be replaced and the corresponding transistor too. (in power supplies equipped with power stages).

Tightness of all screws on power connections.

State and elasticity of the carbon roller springs. (in power supplies equipped with a variable transformer.
Damaged rollers must be replaced.


Remove dust and dirt from the components fans and air filters.


If the power supply must be moved, it is necessary to drain the water circuit.


BRUKER BIOSPIN
Power Electronik Department
34, Rue de l'industrie
67166 WISSEMBOURG CEDEX (FRANCE)
TEL : +33 (0)3 88 73 69 42
FAX : +33 (0)3 88 73 68 86
E-MAIL : power-elec.support@bruker.fr

Wiring diagrams


2









REV	DESCRIPTION	NUMBER	COMMENTS
01	INITIAL	1	
02	REVISED	2	
03	REVISED	3	
04	REVISED	4	
05	REVISED	5	
06	REVISED	6	
07	REVISED	7	
08	REVISED	8	
09	REVISED	9	
10	REVISED	10	
11	REVISED	11	
12	REVISED	12	
13	REVISED	13	
14	REVISED	14	
15	REVISED	15	
16	REVISED	16	
17	REVISED	17	
18	REVISED	18	
19	REVISED	19	
20	REVISED	20	
21	REVISED	21	
22	REVISED	22	
23	REVISED	23	
24	REVISED	24	
25	REVISED	25	
26	REVISED	26	
27	REVISED	27	
28	REVISED	28	
29	REVISED	29	
30	REVISED	30	
31	REVISED	31	
32	REVISED	32	
33	REVISED	33	
34	REVISED	34	
35	REVISED	35	
36	REVISED	36	
37	REVISED	37	
38	REVISED	38	
39	REVISED	39	
40	REVISED	40	
41	REVISED	41	
42	REVISED	42	
43	REVISED	43	
44	REVISED	44	
45	REVISED	45	
46	REVISED	46	
47	REVISED	47	
48	REVISED	48	
49	REVISED	49	
50	REVISED	50	
51	REVISED	51	
52	REVISED	52	
53	REVISED	53	
54	REVISED	54	
55	REVISED	55	
56	REVISED	56	
57	REVISED	57	
58	REVISED	58	
59	REVISED	59	
60	REVISED	60	
61	REVISED	61	
62	REVISED	62	
63	REVISED	63	
64	REVISED	64	
65	REVISED	65	
66	REVISED	66	
67	REVISED	67	
68	REVISED	68	
69	REVISED	69	
70	REVISED	70	
71	REVISED	71	
72	REVISED	72	
73	REVISED	73	
74	REVISED	74	
75	REVISED	75	
76	REVISED	76	
77	REVISED	77	
78	REVISED	78	
79	REVISED	79	
80	REVISED	80	
81	REVISED	81	
82	REVISED	82	
83	REVISED	83	
84	REVISED	84	
85	REVISED	85	
86	REVISED	86	
87	REVISED	87	
88	REVISED	88	
89	REVISED	89	
90	REVISED	90	
91	REVISED	91	
92	REVISED	92	
93	REVISED	93	
94	REVISED	94	
95	REVISED	95	
96	REVISED	96	
97	REVISED	97	
98	REVISED	98	
99	REVISED	99	
100	REVISED	100	



Local control unit electronic boards

3






	BRUKER Analytik	Print No : 9601
		Name : SCHINELL
Size: A3	Title: ADC 12 Bit	Document Number: N3-3S2 631/2
Date: 31-May-2002	Sheet 2 of 7	Revision: 00

DAC 16 Bit & Regulation

3.2.2




BRUKER

Print No: 9611
Name: SCHNELL


Docment Number: N3-32631/3

Title: DAC 16 Bit & Regulation


Date: 31-May-2002 Sheet 3 of 7 Revision: 00



	BRUKER Analytik	Print No.: 9601
	Document Number: N3-3S2631/5	Name: SCHNELL
Size: A3	Title: OUTPUT STAGE	Date: 31-May-2002
		Sheet: 5 of 7
		Revision: 00




	BRUKER Analytik	Print No : 9601
	Document Number: N3-3S2631/4	Name : SCHNELL
	Date: 31-Mar-2002	Sheet 4 of 7
Size: A3	Title: PAL (P.S. Controller)	Revision: 00




— Diese Zeichnung bedeutet dass eine Drahtbrücke eingelötet wird
 RX34, RX35, R38, R47, R78, R79, C33
 werden auf Stützstifte gelötet.


	BRUKER Analytik	Print No : 9601 Name : SCHNELL
	Document Number: N3-3S2631/6	
Size: A3	Title: P.S. controller Jumper & Layout	
Date: 31-May-2002	Sheet: 6 of 7	Revision: 00





	BRUKER Analytik	Print No.: 9601
	Document Number: N3-3S2631/7	Name: SCHNELL
Size: A3	Title: P.S. controller, board address	Date: 31-May-2002
		Sheet: 7 of 7
		Revision: 00





BRUKER	BRUKER	Prin No - 9405
Analytische Messtechnik		Name : SCHNELL
Document Number: N3-S1800/1		
Sheet: 1 of 5		Revision: 00
Date: 31-Dec-1999		






















***REM.CONTROL UNIT
ELCTR.BOARDS***


4



BRUKER	BRUKER Analytik	Print No.: BN9608
		Name : Wegner
Size: A3	Title: Display B-MC20	Document Number: N3-32660/1
Date: 6-Oct-1999	Sheet: 1 of 3	Revision: 00

Part number	Serial number
N1007	X







	Print No.: BN9608
	Name: Wagner
Document Number: N3-3526602	Revision: 00
Title: Alpha Numeric Display	Sheet: 2 of 3
Date: 6-Oct-1999	

REM.CONTROL UNIT ELCTR.BOARDS

Keyboard BMC20

4.1.2






	BRUKER Analytik	Print No.: BN9/09
		Name: Wagner
Document Number: N3-3S2772/1		
Size: A3	Title: Display CPU Interface	
Date: 19-Jan-2000	Sheet: 1 of 2	Revision: 00

REM.CONTROL UNIT ELCTR.BOARDS

Key and Led I/O

4.2.1




	BRUKER Analytik	Print No : BN9609
	Document Number : N3-3S2772/2	Name : Wägener
Size: A3	Title : Key and LED I/O	Date : 19-Jan-2000
		Sheet: 2 of 2
		Revision: 00

REM.CONTROL UNIT ELCTR.BOARDS

Layout


4.3.1



	BRUKER Analytik	Print No: 8608
		Name: Schnell
	Document Number: N3-3S995/2	
Size: A3	Title: Layout Jumper PARALLEL I/O	
Date: 6-Dec-2000	Sheet: 2 of 2	Revision: 00


Cabinet electronic boards


5





REV	MODIFIED/DATE	NUMBER	COMMENTS																		
<table border="1" style="width:100%; border-collapse: collapse;"> <tr> <td style="width:33%;">ART: W1210471</td> <td style="width:33%;">EC:</td> <td style="width:33%;">DRAWN: AKL</td> <td style="width:33%;">DATE: 10/09/1999</td> <td style="width:33%;">VISA:</td> </tr> <tr> <td colspan="2" rowspan="2" style="text-align: center; vertical-align: middle;"> BPS REG3210 STEERER </td> <td colspan="2">APPROV:</td> <td>VISA:</td> </tr> <tr> <td colspan="2">DATE:</td> <td></td> </tr> <tr> <td colspan="2">DWG: W4S12 5299</td> <td>A</td> <td colspan="2">SHEET: 1/4</td> </tr> </table>				ART: W1210471	EC:	DRAWN: AKL	DATE: 10/09/1999	VISA:	BPS REG3210 STEERER		APPROV:		VISA:	DATE:			DWG: W4S12 5299		A	SHEET: 1/4	
ART: W1210471	EC:	DRAWN: AKL	DATE: 10/09/1999	VISA:																	
BPS REG3210 STEERER		APPROV:		VISA:																	
		DATE:																			
DWG: W4S12 5299		A	SHEET: 1/4																		











Power stage

5.3

